

ATR-1RLH ESD Safe Utility Cart



The cart is designed to work as a mobile work station and to transport static sensitive parts and equipment.

Features:

- Fully Static Safe with truly ESD safe wheels and the grounding chain
- Solidly built with epoxy powder coated aluminum
- Equipped with large, Non-Marking ESD Safe wheels
- The Top Shelf lined with Static Safe, Non-Burn rubber mat
- Ergonomic handle on the front of top shelf to pull or to push the cart
- 10mm Grounding Snap on the side of the top shelf and 6ft Grounding Coil cord to safely ground the cart and discharge static if used on Non-ESD floors
- Prepared to accept the optional middle shelf (Bokar P/N ATR-RL/ms)

P/N X-DOC402
June 29/2021
Rev. A

650 Scranton Pocono Hwy.,
Covington Twp., PA 18444, USA
Tel: (570) 842-2812 Fax: (570) 842-4290
E-Mail: bokar@bokar.com

www.bokar.com



Technical Specifications:

MODEL	ATR-1RLH
Load capacity	300 lb. (140 Kg)
Top shelf dimensions	23.6" W x 43.3" L x 36.8" H (600 W x 1100 L x 935 H mm)
System Dimensions	24.2" W x 45.9" L x 36.8" H (614 W x 1166 L x 935 H mm)
Weight	40 lbs. (18 kg)
Packaged weight	55 lbs. (25 kg)
Packaged dimensions	25.6" W x 47.1" W x 7.9" H (645 W x 1195 W x 200 H mm)


Assembly Instructions

Content of the Box:

1. Two Platforms
 - Top platform with ESD rubber
 - Bottom platform with 4 ESD Safe Wheels (two stationary and two rotary with brakes)
2. Handle with 2 screw M8
3. 4 Legs
4. 32 Screws (M5x10)
5. 32 Star Washers (M5)
6. 1 Hex Wrench (3mm)





A). Attach the handle on the outside of the top platform using 2 M8 screws (see below).






B). Attach the Legs to the Platform with Wheels Using 16 M5 Screws and

16 M5 washers in the order Shown Below:



C). Attach the Legs to the Top Shelf in the Same Order B).





SMT: www.Assembly-SMT.com www.FineRework.com www.X-Reflow306.com,
www.X-1003.com www.SMTrepair.com www.SMTFocus.com
www.SMTdispenser.com www.BestBatchOven.com www.SMT-tool.com

ESD: www.ESDapparel.com www.ESDmeters.com www.ESDpackaging.net
www.ZeroCharge.net www.No-Stat.com www.ESDchair.com
www.ESDlabcoats.com www.ESDcarts.net www.ESDbrushes.com

Other: www.SMT-ESD.com www.SuperiorScrewdrivers.com www.Super-Iron.com

Latest Additions: www.esdgloves.info www.FumeXtraction.com www.ULT.de (excellent German made Fume extractors)



BOKAR International
650 Scranton Pocono Hwy.,
Covington Twp., PA 18444, USA
Tel: (570) 842-2812 Fax: (570) 842-4290
e-mail: bokar@bokar.com

www.bokar.com

US Master Distributor: www.bomir.com

e-mail: bomir@bomir.com